



Ethernet Manual (Add Port)


:: Windows Driver ::




Select Settings in Start and Click Printers and Faxes.




After clicking the printer in connection, click the right side button of your mouse and select Properties.



Click the Ports Tab in the Properties window and click Add Port.



To add a port, select Standard TCP/IP Port in Printer Ports window and click New Port.



Add Standard TCP/IP Printer Port Wizard

Add Port
For which device do you want to add a port?

Enter the Printer Name or IP address, and a port name for the desired device.

Printer Name or IP Address: 192.168.0.128

Port Name: IP_192.168.0.128

< Back Next > Cancel

Insert IP Address of the connected printer and click Next.

Add Standard TCP/IP Printer Port Wizard

Additional Port Information Required
The device could not be identified.

The device is not found on the network. Be sure that:

1. The device is turned on.
2. The network is connected.
3. The device is properly configured.
4. The address on the previous page is correct.

If you think the address is not correct, click Back to return to the previous page. Then correct the address and perform another search on the network. If you are sure the address is correct, select the device type below.


Device Type

☐ Standard Generic Network Card


☒ Custom Settings...

< Back Next > Cancel

Select Custom and click Next.



Click Finish and finish the Wizard.



Select the port of the installed printer and click OK.