

1. Extract this archive creating the vendorcupsinstall directory automatically.

```
# tar -zxvf vendorcupsinstall_20061221.tar.gz
```

2. Open your favorite shell (bash, etc.) and move to the vendorcupsinstall directory.

```
# cd vendorcupsinstall
```

3. Execute the 'su' command to obtain super-user level permissions.

You must enter the root user's password for this to succeed. Be careful!.

4. Type 'make install' to install this package onto your computer.

```
# make install [Enter]
```

A successfull install should result in output similar to this:

```
# installing
```

```
cp ppd/*.gz install
```

```
cd install; exec ./setup
```

```
VENDOR THERMAL PRINTER
```

```
VENDOR THERMAL PRINTER CUPS Driver 1.0.0 installation Start
```

```
-----
```

```
Models included:
```

```
        VENDOR THERMAL PRINTER
```

```
Searching for ServerRoot, ServerBin, and DataDir tags in /etc/cups/cupsd.conf
```

```
ServerBin tag is present as an absolute path
```

```
DataDir tag is present as an absolute path
```

```
ServerRoot = /etc/cups
```

```
ServerBin  = /usr/lib/cups
```

```
DataDir    = /usr/share/cups
```

```
Copying rastertovtp filter to //usr/lib/cups/filter
```

```
Copying Model PPD files to //usr/share/cups/model/VendorTP
```

```
Restarting CUPS
```

```
Shutting down cupsd..done
```

```
Starting cupsd..done
```

Install Complete

Add printer queue using K Menu -> Utilities -> Printing -> Printing Manager, or

Add printer queue using OS tool, <http://localhost:631>, or <http://127.0.0.1:631>

5. Goto <http://127.0.0.1:631> or use your favorite CUPS admin tool.

Or K Menu -> Utilities -> Printing -> Printing Manager.

How to Add Printer

K Menu -> Utilities -> Printing -> Printing Manager.

Add ➔ Add Printer/Class... ➔ Next

➔ Local Printer(Parallel, Serial, USB)

Or Network Printer(TCP)

➔ Manufacturer(VENDOR THERMAL PRINTER) and Model(VENDOR THERMAL Receipt Printer)

➔ End.